




WL30-M PARTS DIAGRAM




1	PA018A01	Top Lid
---	----------	---------




1	PH044A01	Face Plate WL30
4	EB083A01	Front LED PCB
5	PB036A01	Upper Front Panel
6	PK128A01	Dispense Cover




1	PD021A01	Drip Tray Float Cover
2	PD046A01	Drip Tray Grill
3	PD022A01	Drip Tray Float
4	PD047A01	Drip Tray
6	PC013A01	Lower Front Panel





1	PE001C02	Rear Panel
3	ED002A01	Hot Switch
4	EJ003A01	Fuse Housing & Cap







1	FL005A01	QC Filter Head Assy
2	WL-QC1	Sediment Filter
3	WL-QC2	Pre-Carbon Filter
4	WL-QCLEAD	Lead Reduction Filter
5	WT-QC5	Post Carbon Filter
6	WL-QCBP	Bypass Plug




4	EF014A01	Cold Tank Thermostat
8	PG034A01	Cold Tank Lid
10	PF073A01	Float
11	AF	Air Filter
13	EH005A01	UV LED



4	TB021A01	Hot Tank
6	RC006K01	Hot Inlet Silicone
8	RB002K01	Drain Hose
10	RC036K01	Pump to Hot Silicone
15	RC039K01	Hot Pump Silicone
17	RC037A01	Cold to Hot Silicone



1	EC011A01	Dispense Solenoid
3	RC049K01	Hot Valve Silicone
6	RC048K01	Cold Valve Silicone
9	EE011A01	Cold Water Pump
12	RC033K01	Cold Water Outlet Silicone



2	11-1546-1	Leak Stop
4	PK113A01	Foot
5	RC043K01	Leak Tray Plug

WL30-M WATER FLOW DIAGRAM (MICRO-FILTRATION CONFIG)

