



# Aramark Countertop and Refresh Centers

## MANUAL



Waterlogic Commercial Products, LLC  
3175 Bass Pro Drive – Grapevine, TX 76051  
(800) 288-1891      [www.waterlogic.us](http://www.waterlogic.us)  
Tech Portal Website: [aramark-portal.waterlogic.com](http://aramark-portal.waterlogic.com)

Aramark Headquarters: 1101 Market Street – Philadelphia, Pennsylvania 19107

## **ARAMARK COUNTERTOP AND REFRESH CENTERS MANUAL**

Congratulations on your choice of the **Aramark** water treatment system. The **Aramark Countertop and Refresh Centers** dispense cold, and hot water. The 12-RCPC-1 dispenses cold water only. Every **Aramark Water Treatment System** includes:



***Bio-Cote Anti-Microbial Protection***



***Advanced In-Tank Ultraviolet (UV) Purification***



***Filter configuration can be optimized for all water conditions***

The **Aramark Countertop and Refresh Centers** provide exceptional quality and great tasting water with every use.

## **INTRODUCTION**

Carefully read and follow all instructions to ensure proper and efficient operation of your **Aramark Countertop and Refresh Center**. Contact **Waterlogic** or an **Authorized Waterlogic Dealer** if you have any questions.

**Waterlogic** and **Authorized Waterlogic Dealers** employ trained service personnel who are experienced in the installation, function and repair of **Waterlogic** equipment. This publication is written for use by these qualified individuals. **Waterlogic** encourages users to learn about products, however, we believe that product knowledge and service is best obtained by consulting **Waterlogic** or an **Authorized Waterlogic Dealer**.

**Waterlogic Water Treatment Systems** should be combined with selected water treatment components to create a system specifically tailored for each application by trained and qualified personnel.

Products manufactured and marketed by **Waterlogic** and its affiliates are protected by patents issued or pending in the United States and other countries.

**Waterlogic** reserves the right to change the specifications referred to in this literature at any time, without prior notice. Changes or modifications not expressly approved by **Waterlogic** could void the warranty and user's authority to operate the equipment.

## TABLE OF CONTENTS

### USER GUIDE

|                                |    |
|--------------------------------|----|
| • Safety Alert Symbols .....   | 4  |
| • Safety Precautions .....     | 4  |
| • Features and Benefits .....  | 6  |
| • Certifications .....         | 7  |
| • Specifications .....         | 8  |
| • Operating Instructions ..... | 11 |
| • Warranty .....               | 12 |

### SERVICE GUIDE

|                                                             |    |
|-------------------------------------------------------------|----|
| • Service Requirements .....                                | 13 |
| • Hot Tank Principles of Operation .....                    | 15 |
| • Resetting the Hot Tank Overload (High Limit Safety) ..... | 16 |
| • Hot Tank Descaling .....                                  | 18 |
| • LG Compressor Upgrade .....                               | 20 |
| • Replacement Components (Consumables) .....                | 21 |
| • Countertop Drawings and Parts List .....                  | 22 |
| • Refresh Center Drawings and Parts List .....              | 29 |
| • Assembling Single RC-1 .....                              | 37 |
| • Assembling Double RC-2 .....                              | 40 |
| • Counter Top Flow Diagram .....                            | 45 |
| • Refresh Center Flow Diagram .....                         | 46 |
| • Adjusting Cold Water Set Point .....                      | 47 |
| • Electrical Schematic .....                                | 48 |

### INSTALLATION GUIDE

|                                           |    |
|-------------------------------------------|----|
| • Pre-Installation Procedures .....       | 49 |
| • Countertop Draining Procedure .....     | 53 |
| • Refresh Center Draining Procedure ..... | 55 |
| • Installation Instructions .....         | 57 |

### TROUBLESHOOTING GUIDE

|                                    |    |
|------------------------------------|----|
| • Fault Code .....                 | 60 |
| • Power Troubleshooting .....      | 61 |
| • Dispense Troubleshooting .....   | 63 |
| • Cold Water Troubleshooting ..... | 75 |
| • Hot Water Troubleshooting .....  | 76 |



## **SAFETY ALERT SYMBOLS**

Read and follow all safety information carefully. The signal words used in this manual are selected as shown below and based on an assessment of the degree of potential injury or damage (severe or minor) and the occurrence of injury (definitely occurs or has the potential to occur) when the warning is ignored:

 **DANGER!**

*Indicates a situation which, when not avoided, results in death or severe injury.*

 **WARNING!**

*Indicates a situation which, when not avoided, has the potential to result in death or severe injury; and/or severe property damage.*

 **CAUTION!**

*Indicates a situation which, when not avoided, results or has the potential to result in minor injury; and/or minor property damage.*

## **SAFETY PRECAUTIONS**

### **Basic safety precautions should be followed, including the following:**

Ensure all Local, State, and Federal Laws and Codes including health and safety guidelines are met when installing **Waterlogic** Equipment. Only qualified service technicians should attempt installation and service of **Waterlogic** Equipment. Always read the entire operating instructions before using the appliance and save these instructions for future use.

 **DANGER!** *This product can cause death or severe injury if incorrectly operated, installed or maintained. The installation, maintenance, sanitizing and any repair must be performed by qualified persons trained by Waterlogic International or their approved distributors only. Do not remove any panel or cover to protect against electrical shock and exposure to UV radiation.*

 **DANGER! ELECTRICAL SHOCK HAZARD.** *Always use a dedicated and properly grounded outlet. Unit should be protected by ground-fault circuit interrupter (GFCI) or residual current device (RCD) having a rated residual operating current not exceeding 30mA. Use only Waterlogic supplied power cord. Never use extension cords or power strips to connect unit. Do not use if the power supply cord is damaged. Always unplug from power supply prior to servicing.*

 **WARNING! AUTHORIZED USE ONLY.** *This appliance is to be used for its intended purpose as described in this manual and untrained individuals who use this manual assume the risk of any resulting property damage or personal injury. This appliance can't be used by children and persons with reduced physical, sensory or mental capabilities or lack of experience.*

 **WARNING! UV-C EMITTER (UV LAMP).** *This appliance contains a UV-C emitter (UV Lamp). UV-C radiation may, even in little doses, cause harm to the eyes and skin. Unintended use or damage to the housing may result in the escape of dangerous UV-C radiation. Never operate the UV-C emitter if damaged or removed from enclosure. Do not touch or look directly into the faucet.*

- ⚠ WARNING! DO NOT OPERATE IF DAMAGED.** Unplug and isolate water supply if abnormal conditions exist. Contact Waterlogic or authorized dealer for repair, service, and installation to avoid hazards.
- ⚠ WARNING! HOT WATER.** Unit produces Hot Water in excess of 80°C (175°F). Water above 52°C (125°F) can cause severe burns or scalding. Keep unauthorized people and children away from the unit to avoid accidental dispensing of hot water.
- ⚠ WARNING! CONNECT TO POTABLE WATER SUPPLY.** This system is to be used for water only and is not intended for use where water is microbiologically unsafe or with water of unknown quality without adequate disinfection before or after the system.
- ⚠ WARNING! TIP HAZARD.** Dispenser could tip or fall causing serious injury. Always install unit on a firm, flat, and level surface and secure unit to cabinet, wall, or floor if needed. Never place heavy items on top of unit and never climb, stand, or hang on unit or storage cabinet to prevent injury and damage.
- ⚠ WARNING! UNIT IS HEAVY. TWO PERSON LIFT REQUIRED.** Transport unit empty and always use material handling equipment or two people with proper lifting technique to reduce injury risk.
- ⚠ WARNING! STORE AND TRANSPORT UNIT EMPTY. ALWAYS SANITIZE BEFORE USE.**  
The unit must be completely drained before storing to avoid stagnation and reduce microbiological contamination (potential bacterial growth). Always sanitize before use to eliminate any potential microbiological contaminants.
- ⚠ CAUTION! INDOOR USE ONLY.** Never expose to direct sunlight, heat sources, or ambient air temperature above 37°C (100°F) or below 2°C (35°F). Install indoors and keep unit away from excessive humidity. Never expose to freezing temperatures. Ensure there is adequate clearance around the unit to allow refrigeration system condenser to dissipate heat. Warmer environments require more clearance around the unit. Minimum clearance around all surfaces of the machine is 2-inches. Installs where the ambient temperature exceeds 27°C (80°F), require a minimum of 4-inches clearance for proper heat dissipation and efficient operation.
- ⚠ CAUTION! USE A WATER PRESSURE REGULATOR.** Waterlogic will not be responsible for injury or damage caused by excessive water pressure. Input or feed pressure must be 40 psi to 60 psi. Be aware of any potential pressure surges caused by building/municipal pumping stations.
- ⚠ CAUTION! USE UV STABILIZED SUPPLY LINES.** Feed the unit with a potable ambient or cold water supply only. Feed water over 37°C (100°F) can damage the treatment components. Water block devices and external leak detectors are strongly recommended. Locate the unit as close to the water supply and the electrical connections as possible. Immediately isolate or close water supply valve and contact service representative if leak is noticed.

**Contact Waterlogic for assistance or help finding an Authorized Service Representative.**

## **ARAMARK COUNTERTOP AND REFRESH CENTERS FEATURES AND BENEFITS**

### **Cold and Hot Water**

**Aramark Countertop and Refresh Centers** come standard with Cold and Hot Selections to meet a wide range of customer demands. The **12-RCPC-1** Refresh Center comes standard with our Cold Only Water Version.

### **High Volume Storage and Water Capacity**

Refresh Center Models have 4 liters of Cold Water Capacity and 1.6 Liters of Hot Water Capacity. Counter Top has 2 liters of Cold Water Capacity and 1.6 Liters of Hot Water Capacity.

### **BioCote® Anti-Microbial Protection**

Certain plastic, silicon, and painted surfaces surrounding the dispensing areas and drip tray are infused with an exclusive additive called BioCote®. BioCote® provides an effective barrier against microbes like bacteria and mold, which may cause odors or staining.



### **Large Dispense Area with Recessed Faucet**

8.5 inch dispense height with BioCote® recessed faucet to protect from cross-contamination.

### **Leak Detection**

**Aramark Countertop and Refresh Centers** are supplied with a Sensor in the Leak Tray that halts water supply to prevent overflow and sounds alarm to reduce accident potential.

### **Child Safeguard**

**Aramark Countertop and Refresh Centers** requires the Hot Water dispensing button followed by the Main Dispense for Hot Water, and defaults back to cold selection after 3 seconds of inactivity to prevent accidental dispensing of hot water.

### **Energy Saving Sleep Mode**

Energy Saving Sleep Mode turns off the Hot Tank when no Hot Water is dispensed for 3 hours. Touching the Hot Dispense Button turn the Hot Tank back on. The Energy Saving Sleep Mode can be programmed to be disabled.

### **In-Tank UV Purification**

Industry leading In-Tank UV Purification prevents the growth of bio-film within the Stainless Steel Cold Tank.

### **Auxiliary Port**

Auxiliary Port to feed Coffee Machines or other Appliances on **Aramark Countertop and Refresh Centers**.

